

Foamtak™ Spray Adhesive

Installation & User Guide



DIRECTIONS FOR USE: *(Orange color formulation. Clear formulation, refer to package instructions.)*

- 1 Shake can for 30 seconds., this formulation does not require a mixing ball.
 - 2 Hold can 3-5 inches from the surface to be sprayed.
 - 3 Spray both surfaces to be bonded.
 - 4 Allow adhesive to dry a minimum of 60-75 seconds. Test periodically for tackiness with knuckle.
 - 5 Firmly press the two surfaces together while adhesive is still tacky. After use, clean spray tip with turpentine. When using solvents for cleanup, follow the manufacturer's precautions and directions for use.
- **Standard Foam Bonds:** For thinner foam panels (*1 to 2" thick*) spraying the perimeter and an X or zig zag pattern in the middle should be sufficient. Total coverage is not required. Mirror this pattern on the mounting surface for best adhesion.
 - **Extra Strong Foam Bonds:** (*Thicker or heavier pieces of foam and when adhering to fabric or wood*): Spray adhesive on foam surface. Double coat the other surface, applying the second coat in a cross direction to the first coat, total coverage is recommended. Join coated surfaces within 5 minutes. *Allow several minutes to completely dry.*
 - **Tack Range:** 45 seconds to 10 minutes (*temperature and humidity dependant*). Test tackiness with a disposable item. When there is a slight pull or resistance, when removing the item, the adhesive is ready for immediate installation.
 - **Foamtak** is considered a permanent installation. Removing the panel after the adhesive has cured can result in some damage to the **Studiofoam** and the mounting surface. Try using a sharp knife to carefully separate the panel from the adhesive to minimize tearing. Use a citrus based adhesive remover to clean the adhesive from the wall. **Auralex** is not responsible for any damage to walls, the ceiling or the overall structure that occurs during installation or removal of our products.

Real-World Acoustics®

1-800-959-3343 | 317-842-2600 | Auralex.com
9955 Westpoint Drive, Suite 101, Indianapolis IN USA 46256

1568-717.Foamtak Spray Web Application Tips (01/13/2020 - 11:37 AM)

Foamtak™ Spray Adhesive

Installation & User Guide



DIRECTIONS FOR USE: *(Orange color formulation. Clear formulation, refer to package instructions.)*

- 1 Shake can for 30 seconds., this formulation does not require a mixing ball.
 - 2 Hold can 3-5 inches from the surface to be sprayed.
 - 3 Spray both surfaces to be bonded.
 - 4 Allow adhesive to dry a minimum of 60-75 seconds. Test periodically for tackiness with knuckle.
 - 5 Firmly press the two surfaces together while adhesive is still tacky. After use, clean spray tip with turpentine. When using solvents for cleanup, follow the manufacturer's precautions and directions for use.
- **Standard Foam Bonds:** For thinner foam panels (*1 to 2" thick*) spraying the perimeter and an X or zig zag pattern in the middle should be sufficient. Total coverage is not required. Mirror this pattern on the mounting surface for best adhesion.
 - **Extra Strong Foam Bonds:** (*Thicker or heavier pieces of foam and when adhering to fabric or wood*): Spray adhesive on foam surface. Double coat the other surface, applying the second coat in a cross direction to the first coat, total coverage is recommended. Join coated surfaces within 5 minutes. *Allow several minutes to completely dry.*
 - **Tack Range:** 45 seconds to 10 minutes (*temperature and humidity dependant*). Test tackiness with a disposable item. When there is a slight pull or resistance, when removing the item, the adhesive is ready for immediate installation.
 - **Foamtak** is considered a permanent installation. Removing the panel after the adhesive has cured can result in some damage to the **Studiofoam** and the mounting surface. Try using a sharp knife to carefully separate the panel from the adhesive to minimize tearing. Use a citrus based adhesive remover to clean the adhesive from the wall. **Auralex** is not responsible for any damage to walls, the ceiling or the overall structure that occurs during installation or removal of our products.

Real-World Acoustics®

1-800-959-3343 | 317-842-2600 | Auralex.com
9955 Westpoint Drive, Suite 101, Indianapolis IN USA 46256

1568-717.Foamtak Spray Web Application Tips (01/13/2020 - 11:37 AM)