# **Roominator™ Starter Kit**



The **Auralex Roominator™ Starter Kit** offers you a starting point to reduce unwanted slap and flutter echo in your room. Perfect for small home studios, audio and video editing suites, podcasting spaces, vocal booths and home listening environments, the **Roominator™ Starter Kit™** is designed to immediately improve the acoustics of any small- to medium- size room.

Positioning the included **LENRD® Bass Traps** in the corners of the room will control low-frequency room nodes — a very important thing to do in small rooms! As your needs change it is easy to add additional **Studiofoam®** acoustical treatment to further improve the acoustics of your space.



All copyrightable materials are © Copyright 2019-2020, Auralex Acoustics, Inc. Auralex, Total Sound Control, Real-World Acoustics, Studiofoam and LENRD are registered trademarks, and EZ-Stick Pro is a trademark, of Auralex Acoustics, Inc. All rights reserved. Designed and manufactured in the U.S.A.

**1-800-959-3343 / 317-842-2600** 9955 Westpoint Drive, Suite 101, Indianapolis IN USA 46256



# **Roominator**<sup>™</sup> Starter Kit

# **GENERAL PLACEMENT SUGGESTIONS**

### STUDIOFOAM:

**Studiofoam Wedges** panels reduce mid-high frequency reflections, flutter echo, room ring and excessive reverberation. To maximize performance in a project studio or control room, consider placing the panels at the first reflection points located to the sides, front, rear and ceiling above your listening position. To maximize performance in a live room, consider spacing the panels evenly throughout the room and staggering treatment across parallel surfaces.

## LENRD: Low End Noise Reduction Device

**LENRD Bass Traps** are designed for the 90 degree corners of a room. To increase performance, place them vertically between adjacent walls and horizontally between a wall and the ceiling.

Studiofoam® Wedges and LENRD® Bass Traps can be mounted to standard drywall with the included EZ-Stick Pro<sup>TM</sup> Tabs. Be advised that the EZ-Stick Pro Tabs are designed for permanent installations and will damage drywall and painted surfaces when removed.

Mark the target position on your wall or ceiling where the product will be mounted using small pencil marks, pieces of masking tape or any similar non marring method. Be sure the surface where the **EZ-Stick Pro Tabs** will adhere is free of dirt, dust or other oily contaminants by spot cleaning with rubbing alcohol.

**Studiofoam Wedges Panels** and **LENRD Bass Traps** use **(4) EZ-Stick Pro Tabs** each.

Remove one of the release layers on the **EZ-Stick Pro Tabs** and affix it to the rear side of the products perimeter, usually near the corners. Apply firm pressure and wait about 5 minutes for the adhesive to set.

Remove the second layer of the release paper from each of the **EZ-Stick Pro Tabs**, carefully orient the panels position prior to contact with the wall, then press in place with moderate pressure.

# **SPECIFIC PLACEMENT SUGGESTIONS**



#### FREE PERSONALIZED ROOM ANALYSIS:

For specific placement suggestions regarding your room, feel free to submit a free **Personalized Room Analysis** form online at: <a href="www.Auralex.com/praf/">www.Auralex.com/praf/</a>. You provide information about your room including a room diagram and photos. **Auralex** will diagram your room, including all surfaces with product placement indicated.



#### **ROOM ANALYSIS PLUS:**

For a more in depth analysis of your room, we offer the **Room Analysis Plus** service. We supply the frequency sweeps, you send us the recordings of your room and we'll deliver more detailed suggestions based on our findings. Contact your **Authorized Auralex Dealer** for pricing.



### RLX™ ROOM LAYOUT EXPRESS APP:

The RLX™ (Room Layout eXpress™) is an automated acoustic treatment mobile app that is specifically designed to give instantaneous recommendations for various room types. The app is both easy to use and returns immediate results. Available FREE on the Apple® App Store and Google® Play.

1-800-959-3343 / 317-842-2600