# **Stand-Mounted LENRD®**

### **Installation & User Guide**

Thank you for purchasing the Auralex<sup>®</sup> Stand-Mounted LENRD<sup>®</sup> Bass Traps. This is a highly effective portable acoustic bass trap that can be easily positioned in your rooms corners to improve low frequency absorption.

• Set up stand firmly tighten the pole into the base. Extend the top tube and firmly tighten the adjustment collar.



Remove star washer from the top of Ø the stand if present.



### **Real-World Acoustics**\*

• Lay the LENRD on a flat surface and open up the gap in the rear to remove the foam tube from the stand hole. Insert the stand tube into the center hole. This is often best accomplished with the LENRD lying flat on the floor or on a table. Adjust the height of the LENRD as required.





 Position the LENRDs in the corners of your room. For optimal bass trapping, adjust the height of the LENRDs so they are as close to the ceiling as possible.



1-800-959-3343 | 317-842-2600 | Auralex.com 9955 Westpoint Drive, Suite 101, Indianapolis IN USA 46256

1718-918.Stand-Mounted LENRD User Guide (03/05/2020 - 1:02 PM)

## **Stand-Mounted LENRD®**

### **Installation & User Guide**

Thank you for purchasing the Auralex<sup>®</sup> Stand-Mounted LENRD<sup>®</sup> Bass Traps. This is a highly effective portable acoustic bass trap that can be easily positioned in your rooms corners to improve low frequency absorption.

• Set up stand firmly tighten the pole into the base. Extend the top tube and firmly tighten the adjustment collar.



Ø Remove star washer from the top of the stand if present.



### **Real-World Acoustics**<sup>®</sup>

3 Lay the LENRD on a flat surface and open up the gap in the rear to remove the foam tube from the stand hole. Insert the stand tube into the center hole. This is often best accomplished with the LENRD lying flat on the floor or on a table. Adjust the height of the LENRD as required.





optimal bass trapping, adjust the height of the LENRDs so they are as close to the ceiling as possible.



1-800-959-3343 | 317-842-2600 | Auralex.com 9955 Westpoint Drive, Suite 101, Indianapolis IN USA 46256

- Bound Control® Sin www.auralex.com
- Position the LENRDs in the corners of your room. For

